
























Nrf nr 6122394

Monteringsanvisning såpeinnsats for og TECEnow betjeningsplate med installasjonsramme









- 6122462 TECEnow betjeningsplate, forkrommet
- 6122461 TECEnow betjeningsplate, hvit
- 6122463 TECEnow betjeningsplate, matt krom
- 6122464 TECEnow betjeningsplate, sort
- 6122297 Installasjonsramme for betjeningsplate WC, hvit
- 6122298 Installasjonsramme for betjeningsplate WC, sort
- 6122299 Installasjonsramme for betjeningsplate WC, gull
- 6122301 Installasjonsramme for betjeningsplate WC, forkrommet